

ErgoTight Pro compact wireless keyboard + ErgoTight Pro numeric keyboard

3200501RF – ErgoTight Pro compact RF wireless- US:

This product can be used wirelessly from the box by plugging the included RF dongle into the USB port of your PC or laptop. The included USB cable is your charging cable for the rechargeable battery, which is built into the keyboard.

Before using your ErgoTight Pro Design ultra-slim wireless compact keyboard for the first time, you must charge it for at least 24 hours with the USB cable. When charging the keyboard, the dongle must be plugged into your PC or laptop.

Charging can be done by plugging the supplied USB cable directly into your PC or laptop, or by plugging in a USB plug into the socket (this is not included).

Before you start using the keyboard, there are a few more options that may come in handy when using the keyboard.

As you can see at the bottom left of the keyboard, it contains a blue Fn button. This button allows you to use the other blue colored keys by pressing them simultaneously.

For example, pressing Fn and P at the same time gives you the hyphen "-".

You can also use the ErgoTight integrated numeric, which is possible in combination with the Fn button. This can be done by pressing the Fn button simultaneously with one of the blue keys.

The ErgoTight also has a CAPS LOCK mode. If this is enabled, all letters will be typed in uppercase until the CAPS LOCK is turned off again. The SCROLL LOCK provides a second function of the arrow keys. With the function on you can move through the field with the cursor using the arrow keys until it is turned off. Then it functions like scrolling the page within the window.

When scroll lock is on, the function of the arrow keys is to scroll the content of a text window. In this sense, scroll lock has an equivalent function to the Num Lock and the Caps Lock: it enables a second functionality of a number of keys.

The keyboard also has 2 indicators, which can be found at the top right of the keyboard. The left lamp indicates that the keyboard is empty or if it is on the charger, is charged. The right lamp indicates that the keyboard is correctly connected to the charger.

Furthermore, the content of the box contains a small black connector, with which you can connect the keyboard to the numeric.



3200502-RF – ErgoTight Pro Numpad Wireless / use of the separate numeric keypad

The numerical part also contains an RF dongle, which you can plug into the USB port of your PC or laptop. The included USB cable is your charging cable for the rechargeable battery, which is built into the keyboard.

Before using your ErgoTight Pro Design ultra flat wireless compact numeric for the first time, you must charge it for at least 24 hours with the USB cable. When loading the numeric, the dongle must be plugged into your PC or laptop.

Charging can be done by plugging the supplied USB cable directly into your PC or laptop, or using a USB plug in the wall socket (this is not included).

Ergonomic use

Once this product is also ready for use, you can place it next to your keyboard when needed. This is also a form of ergonomics. Due to this extra flat design, the wrist remains in a neutral flat position and does not have to be curved as with a relatively high standard keyboard. The front can be raised slightly so that it feels even more comfortable with blind and loose typing (piano position).

By using this keyboard, both the mouse and the accompanying numeric keyboard can be used within the body width, so as a right-handed person you can place the numeric keyboard to the right of the keyboard and vice versa. This ensures a more relaxed posture in the neck and shoulder and prevents excessive muscle tension.

The numeric works like any other numeric keypad.

Note: You cannot see whether the numlock is on or off. You will notice this as soon as you press, for example, the 2, 4, 6 or 8 and the page jumps. Once you hit the numlock once again, you can use it numeric as usual.

