

ErgoTight Pro compact keyboard + ErgoTight Pro numeric keyboard

3200501 - ErgoTight Pro Wired Compact Keyboard - US:

This product can be used directly from the packaging by means of a plug & play system. By means of the USB cable you can connect the keyboard to your laptop or PC, after which it is ready for use.

Before you start using the keyboard, there are a few more options that may come in handy when using the keyboard.

As you can see at the bottom left of the keyboard, it contains a blue Fn button. This button allows you to use the other blue colored keys by pressing them simultaneously.

For example, pressing Fn and P at the same time gives you the hyphen "-".

You can also use the ErgoTight integrated numeric, which is possible in combination with the Fn button. This can be done by pressing the Fn button simultaneously with one of the blue keys.

The keyboard also has 2 indicators, which can be found at the top right of the keyboard. The left light indicates that the keyboard is in CAPS LOCK mode. The right light indicates that the keyboard is in SCROLL LOCK mode. The CAPS LOCK means that the letters are written completely in capital letters. The SCROLL LOCK is used to change the behavior of the arrow keys. When scroll lock is on, the function of the arrow keys is to scroll the content of a text window. In this sense, SCROLL LOCK has an equivalent function to the NUM LOCK and the CAPS LOCK: it allows a second functionality of a number of keys.

Furthermore, the content of the box contains a small black connector, with which you can connect the keyboard to the numeric part.



3200502 – ErgoTight Pro Numpad / use of the separate numeric keypad

The ErgoTight numeric keypad comes with two cables. With the small cable you can connect the numeric keypad to the compact keypad. With the long cable you connect the numeric keyboard directly to the computer via a USB port.

Ergonomic use

Once this product is also ready for use, you can place it next to your keyboard when needed. This is also a form of ergonomics. Due to this extra flat design, the wrist remains in a neutral flat position and does not have to be curved as with a relatively high standard keyboard. The front can be raised slightly so that it feels even more comfortable with blind and loose typing (piano position). By using this keyboard, both the mouse and the accompanying numeric keyboard can be used within the body width, so as a right-handed person you can place the numeric keyboard to the right of the keyboard and vice versa. This ensures a more relaxed posture in the neck and shoulder and prevents excessive muscle tension.

The numeric works like any other numeric keypad.

Note: You cannot see whether the numlock is on or off. You will notice this as soon as you press, for example, the 2, 4, 6 or 8 and the page jumps. Once you hit the numlock once again, you can use it numeric as usual.

